


CF7512 Cassette Options

These are the most common options for the MEI CF7512 Cassettes. After replacing the cassette just follow these program instructions.

CODE	Tube Position				
	A	B	C	D	E
MENU +D + AA	10	5	25	25	5
MENU +D + AB	10	5	25	\$1	5
MENU +D + BA	25	5	25	25	25
MENU +D + BB	10	5	10	25	5
MENU +D + DAC	25	5	\$1	\$1	25
MENU +D + DBD	25	5	\$1	\$1	\$1
MENU +D + DCA	25	10	25	\$1	5
MENU +D + DCB	25	10	\$1	\$1	5
MENU +D + DCC	25	10	25	25	5
MENU +D + DCD	5	10	10	10	5
MENU +D + DCE	10	10	10	10	5



888.396.8363 - Atlanta
800.248.1712 - Orlando

www.vendorsrepair.com

V
R
S

T
E
C
H

T
I
P
S